

## FUEL SYSTEM

Remove the main jet, needle jet holder, needle jet and slow jet.

Turn the air screw in and carefully count the number of turns before it seats lightly. Make a note of this to use as a reference when reinstalling the air screw.

### CAUTION

- *Damage to the air screw seat will occur if the air screw is tightened against the seat.*

Remove the air screw and inspect it. Replace it if it is worn or damaged.

Check each part for wear or damage.  
Blow open all jets with compressed air.

## FLOAT CHAMBER ASSEMBLY

Assemble the float chamber components in the reverse order of disassembly.


## CHOKE VALVE

Remove the choke lever pivot screw and choke lever.  
Remove the choke valve nut, spring and valve from the carburetor.


Check the choke valve and spring for nicks, grooves or other damage.

Install the choke valve in the reverse order of removal.


(1) NEEDLE JET HOLDER (2) MAIN JET



(1) SLOW JET (2) NEEDLE JET HOLDER (3) NEEDLE JET



(1) CHOKE LEVER PIVOT SCREW (2) CHOKE VALVE



(1) CHOKE VALVE NUT

