



## FUEL SYSTEM

### CARBURETOR SEPARATION


Remove the throttle stop screw bracket from the carburetor body.



Remove the carburetor attachment screws.  
Carefully separate the ball joint from the ball stud on the secondary throttle drum.



Carefully separate the primary and secondary carburetors.



### THROTTLE VALVE

Remove the two screws attaching the carburetor top cover and the cover.

